


# BEFORE YOU START

## Run the PV Update Client



**INSTALLED VERSION  
AND  
LATEST VERSION  
MUST MATCH**

**IF THESE  
DO NOT MATCH YOU  
NEED TO UPDATE  
YOUR SOFTWARE**

- 1 **Plug the Power Vision into bike you intend to tune**
- 2 **Read ECM on the Power Vision**



**HIT READ ECM**


### 3 Retrieve the Stk Number from Power Vision



WRITE THIS DOWN YOU WILL NEED TO USE THIS NUMBER IN STEP 7

**THIS IS THE STK NUMBER**

### 4 Click Get License in WinPV



# 5 Log in

**USER NAME IS YOUR EMAIL ADDRESS**

**CLICK REFRESH TO LOG IN**

# 6 Plug your Power Vision into your computer

**MAKE SURE THE POWER VISION SCREEN READS *PC LINK MODE ACTIVE* BEFORE YOU MOVE ONTO STEP 7.**



# 7 Click get Stk from PV

The screenshot shows the 'PV Online' application window. It is divided into three main sections: 'Login', 'Account Info', and 'License Action'.  
- **Login:** Includes fields for 'User Name' and 'Password', a 'Remember User Name and Password?' checkbox (checked), and links for 'New User?', 'Forgot?', and 'My Account'.  
- **Account Info:** Shows 'Number of Credits' as '1' with a 'Refresh' button and links for 'Buy Credits' and 'Transfer Credit To...'.  
- **License Action:** A multi-step process:  
 - **Step 1:** Features a 'Get .stk from PV' button highlighted by a red arrow. Below it is a 'Not Loaded' status box. To the right, text reads 'order to generate a license'. Below that are 'Backup .stk' and 'Save .stk' buttons, with the text 'These are optional steps'.  
 - **Step 2:** Features a 'Get License' button. Below it are 'Load License' and 'Restore License' buttons. To the right, text reads 'Generates a License by submitting a credit and .stk from above' and 'These are optional steps to load a license from file, or from PV Online history'.  
 - **Step 3:** Features 'Send License to PV' and 'Save License to File' buttons. Below them is a 'Not loaded' status box. To the right, text reads 'This is your license file that needs to be sent to the Power Vision.'  
At the bottom of the window, there is a checkbox for 'Use OLD 1.0/2014 Server', an 'Exit' button, and a 'Get Help' link.

**CLICK GET .STK FROM PV**





# Highlight the Stk number for the bike you want to tune

## Click Get

PV Online

Login

User Name  [New User?](#)

Password  [Forgot?](#)

Remember User Name and Password?  [My Account](#)

Account

License A

Step 1

Step 2

Step 3

Not loaded

This is your license file that needs to be sent to the Power Vision.

Send License to PV

Save License to File

Use OLD 1.0/2014 Server

Exit

[Get Help](#)

Select STK File to create license for

STK File	Action
07-FF4-JTPOR.7C.stk	Get
09-HPH-5BGSP0F.stk	Get + Delete
10-KB4-A06IV1C.stk	Just Delete
14-TEN-SZRZ6QC.stk	
15-NBB-3NKSUAA.stk	
16-NBB-9NHX5BM.stk	
16-TEN-GS1NLTH.stk	

Cancel

**MAKE SURE THIS IS THE STK NUMBER FOR THE BIKE YOU WANT TO TUNE. YOU RETRIEVED THIS NUMBER DURING STEP 3.**


# 9 Click Get License

The screenshot shows the 'PV Online' web interface. It is divided into three main sections: 'Login', 'Account Info', and 'License Action'.  
1. **Login**: Includes fields for 'User Name' and 'Password', a 'Remember User Name and Password?' checkbox, and links for 'New User?', 'Forgot?', and 'My Account'.  
2. **Account Info**: Features a 'Number of Credits' field with a value of '1' and a 'Refresh' button. This section is highlighted with a red box. Links for 'Buy Credits' and 'Transfer Credit To...' are also present.  
3. **License Action**: A multi-step process:  
- **Step 1**: 'Get .stk from PV' (highlighted in blue), 'Get .stk from file', 'Get .stk from ECM', and 'Clear'. Below this, a file '14-KEL-XSGVKTC.stk' is shown as loaded from PV (164 KB). A text box explains that this is the required '.stk' file for license generation.  
- **Step 2**: 'Get License' (highlighted with a red arrow and the text 'CLICK GET LICENSE'), 'Load License', and 'Restore License'. A text box explains that this is the license file to be sent to the Power Vision.  
- **Step 3**: 'Send License to PV' and 'Save License to File'.  
At the bottom, there is a checkbox for 'Use OLD 1.0/2014 Server', an 'Exit' button, and a 'Get Help' link.

**THERE MUST BE A LICENSE TOKEN IN YOUR ACCOUNT**

**CLICK GET LICENSE**

# 10 Your license has been created Click OK



**CLICK OK**

# 11 Click Send License to PV

PV Online

Login

User Name  [New User?](#)

Password  [Forgot?](#)

Remember User Name and Password?  [My Account](#)

Account Info

Number of Credits   [Buy Credits](#)

[Transfer Credit To...](#)

License Action

Step 1

Loaded From PV (66 KB):  
07-FF4-JTPOR.7C.stk

This is your ".stk" file which is required in order to generate a license

These are optional steps

Step 2

Generates a License by submitting a credit and .stk from above

These are optional steps to load a license from file, or from PV Online history

Loaded from PV Online  
07-FF4-JTPOR.7C.txt

This is your license file that needs to be sent to the Power Vision.

Step 3


Use OLD 1.0/2014 Server  [Get Help](#)

**CLICK SEND LICENSE TO PV**



# 12 Verify that you want to apply this tune license

## Click Yes




13

# Make sure your license has been verified and applied

## Click OK

**IF YOU DO NOT GET THIS VERIFICATION THE LICENSE HAS NOT BEEN APPLIED TO YOUR POWER VISION**



**CLICK OK**

**Now you are ready to tune!**

